

## GM-LZ Vehicle List

	<b>C1</b>	<b>C2</b>	<b>C3</b>
<b>GROUND</b>	BLK	TAN	TAN
<b>FAST</b>	DK-BLU	DK-BLU	DK-BLU/WHT
<b>MUX1</b>	GRY	YEL	GRY
<b>MUX2</b>	PNK	PNK	PNK
<b>VEHICLES</b>	03 - 07 Chevrolet Express 03 - 07 GMC Savana	05 - 07 Chevrolet Silverado 05 - 06 Chevrolet Tahoe 05 - 06 Chevrolet Avalanche 05 - 06 Chevrolet Suburban 05 - 06 GMC Yukon 05 - 06 Cadillac Escalade	04 - 07 Buick Rainier 03 - 04 Cadillac Escalade 03 - 04 Chevrolet Avalanche 03 - 04 Chevrolet Silverado 03 - 05 Chevrolet SSR 03 - 05 Chevrolet Suburban 03 - 04 Chevrolet Tahoe 02 - 07 Chevrolet TrailBlazer 02 - 07 GMC Envoy 02 - 06 GMC Sierra 03 - 04 GMC Yukon 03 - 07 Hummer H2 02 - 04 Oldsmobile Bravada

**This table is for use with the Rain Tracker Quick-Harness.**

**To use this table, find your vehicle in the list and use the corresponding vehicle wire colors.**

**Write the wire colors on the GM-LZ with RT-50 diagram and connect the harness to the corresponding wires.**

**NOTE: Manufacturer supplied documentation can be wrong. If possible, check wire operation with a multimeter**